



**MOLECULAR
SCAFFOLD
SALES**



SAFEMATE

The Safe Way to Erect Scaffold

The *new Molecular SafeMate* upright takes all the risk out of erecting Molecular's Frame Scaffold Systems quickly and easily.

WorkSafe authorities in most states now require scaffold installers to provide safety rails to scaffold platforms prior to accessing them, otherwise a scaffold system is deemed to be not able to be installed over 2 metres.

From the safety of the already protected lower deck, the Molecular SafeMate is installed to provide handrail to the next upper deck. It's that simple. Now you can access the upper deck safely to install mesh guards or the next lift of frames.

The Molecular SafeMate* upright is only approved and compatible to Molecular's Frame Scaffold Systems and is available now.

**Patent Applications for SafeMate and other variations are currently in place.*

1800 SCAFF SALES

1800 722 337

www.molecularscaffold.com.au